

SIMPLY FINE

Simply Stylish



QUALITIER

Authentic Sense of Home Dining

SIMPLY FINE

Simply Stylish

Easy and friendly design. Simply Fine defines well causal and complete tablescape.





Flat Plate

314002	21 cm (8 ¼")
314006	27 cm (10 ⅝")
314015	31 cm (12 ¼")



Coupe Plate

314023	21 cm (8 ¼")
314024	26 cm (10 ⅝")
314025	30 cm (12 ¼")



Deep Plate

314004	23 cm (9")
--------	------------



Oval Plate

314014	30 cm (11 ¾")
314031	36 cm (14 ⅞")



Deep Coupe Plate

314029	21.5 cm (8 ½")
314030	25.5 cm (10")



Bowl

314505	12 cm (4 ¾")
314501	15 cm (5 ⅞")



Coupe Cup & Saucer

314607	100 cc (3 ½ oz)
314017	12.5 cm (4 ⅞")
314601	200 cc (6 ¾ oz)
314018	15 cm (5 ⅞")
314609	250 cc (8 ½ oz)
314018	15 cm (5 ⅞")



Coupe Mug

314612	250 cc (8 ½ oz)
314610	350 cc (11 ¾ oz)



Low Bowl

314507	21 cm (8 ¼")
--------	--------------



Salt Coupe Shaker (1 Hole)

314902

Pepper Coupe Shaker (3 Holes)

314904



Coupe Tea Pot with Lid

314800	1,000 cc (33 ¾ oz)
--------	--------------------



Coupe Sugar Bowl with Lid

314801	200 cc (6 ¾ oz)
--------	-----------------



Coupe Creamer

314802	200 cc (6 ¾ oz)
--------	-----------------



Flat Plate

314002-E055 21 cm (8 ¼")
 314006-E055 27 cm (10 ⅝")
 314015-E055 31 cm (12 ¼")



Deep Plate

314004-E055 23 cm (9")



Oval Plate

314014-E055 30 cm (11 ¾")
 314031-E055 36 cm (14 ⅛")



Coupe Plate

314023-E055 21 cm (8 ¼")
 314024-E055 26 cm (10 ⅝")
 314025-E055 30 cm (12 ¼")



Coupe Mug

314612-E055 250 cc (8 ½ oz)
 314610-E055 350 cc (11 ¾ oz)



Coupe Cup & Saucer

314607-E055 100 cc (3 ½ oz)
 314017-E055 12.5 cm (4 ⅞")
 314601-E055 200 cc (6 ¾ oz)
 314018-E055 15 cm (5 ⅞")
 314609-E055 250 cc (8 ½ oz)
 314018-E055 15 cm (5 ⅞")



Coupe Tea Pot with Lid

314800-E055 1,000 cc (33 ¾ oz)



Coupe Sugar Bowl with Lid

314801-E055 200 cc (6 ¾ oz)



Salt Coupe Shaker (1 Hole)

314902-E055

Pepper Coupe Shaker (3 Holes)

314904-E055



Coupe Creamer

314802-E055 200 cc (6 ¾ oz)



GOLD
BANDING

COLOR GLAZE

MILD STONE



Flat Plate

314002-L141 21 cm (8 ¼")
314006-L141 27 cm (10 ⅝")
314015-L141 31 cm (12 ¼")



Coupe Cup & Saucer

314607-L143 100 cc (3 ½ oz)
314017-L140 12.5 cm (4 ⅞")

314601-L143 200 cc (6 ¾ oz)
314018-L140 15 cm (5 ⅞")

314609-L143 250 cc (8 ½ oz)
314018-L140 15 cm (5 ⅞")



Deep Plate

314004-L141 23 cm (9")



Bowl

314501-L143 15 cm (5 ⅞")



Low Bowl

314507-L143 21 cm (8 ¼")



Coupe Mug

314612-L143 250 cc (8 ½ oz)
314610-L143 350 cc (11 ¾ oz)



LIGHT GREY



Flat Plate

314002-L011 21 cm (8 ¼")
314006-L011 27 cm (10 ⅝")
314015-L011 31 cm (12 ¼")



Coupe Cup & Saucer

314607-L013 100 cc (3 ½ oz)
314017-L010 12.5 cm (4 ⅞")

314601-L013 200 cc (6 ¾ oz)
314018-L010 15 cm (5 ⅞")

314609-L013 250 cc (8 ½ oz)
314018-L010 15 cm (5 ⅞")



Deep Plate

314004-L011 23 cm (9")



Bowl

314501-L013 15 cm (5 ⅞")



Low Bowl

314507-L013 21 cm (8 ¼")



Coupe Mug

314612-L013 250 cc (8 ½ oz)
314610-L013 350 cc (11 ¾ oz)





LA SAGESSE

Charming Ambience

Discover charm of the finest culture, La Sagesse perfectly describes radiant outstanding story decorated on table.



Flat Plate

314002-K015 21 cm (8 ¼")
314006-K015 27 cm (10 ⅝")
314015-K015 31 cm (12 ¼")



Deep Plate

314004-K015 23 cm (9")



Oval Plate

314014-K015 30 cm (11 ¾")
314031-K015 36 cm (14 ⅛")



Bowl

314505-K015 12 cm (4 ¾")
314501-K015 15 cm (5 ⅞")



Low Bowl

314507-K015 21 cm (8 ¼")



Coupe Cup & Saucer

314607-K015 100 cc (3 ½ oz)
314017-K015 12.5 cm (4 ¾")

314601-K015 200 cc (6 ¾ oz)
314018-K015 15 cm (5 ⅞")

314609-K015 250 cc (8 ½ oz)
314018-K015 15 cm (5 ⅞")



Coupe Mug

314612-K015 250 cc (8 ½ oz)
314610-K015 350 cc (11 ¾ oz)



Coupe Tea Pot with Lid

314800-K015 1,000 cc (33 ¾ oz)



Coupe Sugar Bowl with Lid

314801-K015 200 cc (6 ¾ oz)



Coupe Creamer

314802-K015 200 cc (6 ¾ oz)

